



INSTALLATION INSTRUCTIONS

PART No.

FB21237

**Jeep® JK/JL Wrangler & JT Gladiator
Door Mounted Step**



REQUIRED TOOLS

5MM Allen Key

Suggested:
Help of a friend

KIT CONTAINS

Door Mounted Step
Aluminum Spacer
M8 Button Head Bolt
Foam

QTY

1
4
4

2123700

INSTALLATION INSTRUCTIONS

PART No.

FB21237

**Jeep® JK/JL Wrangler & JT Gladiator
Door Mounted Step**

1) REMOVE HINGE BOLTS

With a 5MM Allen wrench, begin removing the (2) bolts from the upper and lower door hinges, while applying constant pressure to hold the door in place and aligned. You may need the help of a friend.



Loosely screw them in by hand, while ensuring the door maintains its alignment and position.

Finally, with a 5MM Allen wrench, tighten down each bolt.



2) INSTALL BOLTS

If you own a JL Wrangler or JT Gladiator, you will need to apply the included foam to the vehicle-side of the brackets to prevent damage to the body's paint.

With the Step in hand, thread the (4) included button head bolts through its brackets and place a spacer on each so that they fit into the hinge holes.

ENJOY YOUR NEW FISHBONE OFFROAD DOOR MOUNTED STEP!

