

Custom Neoprene Seat Covers

Installation Manual: For 2018 - Current Jeep Wrangler JL Vehicles #14167.40XX For 2020 - Current Jeep Gladiator JT Vehicles #14167.41XX



PARTS LIST: Front Seat Cover Set Rear Seat Cover Set **REQUIRED TOOLS:** No Tools Required




READ ALL SAFETY MESSAGES AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL THIS PRODUCT. ALWAYS WEAR SAFETY GLASSES DURING INSTALL.



A Few Words About Product Safety:

Your Diver Down[®] seat covers are intended to protect your seats and enhance the comfort and style of your vehicle's interior. Before installation, please take a moment to review the following safety information and installation instructions. Important safety information is generally preceded by one of three signal words indicating the relative risk of injury. The signal words mean:



Seat Covers Installation:

Prepare your seat covers for installation. Make sure to unbuckle all straps and unzip all zippers on your seat covers prior to installation.

Remove front headrests by depressing the release tabs at the base of the headrest posts and lift up on headrest.



Front seat covers are designed specifically for the passenger and driver side of the vehicle and are not interchangeable. The Diver Down sew bar tags on front seats always face to the center of the vehicle.



YOUR VEHICLE IS EQUIPPED WITH SIDE IMPACT AIRBAGS. MAKE SURE THAT YOU INSTALL THE CORRECT SEAT COVERS FOR YOUR YEAR AND MODEL. ALSO ENSURE THAT PASSENGER AND DRIVER SIDE SEAT COVERS ARE INSTALLED ON THE CORRECT SEAT. FAILURE TO DO SO COULD LESSEN THE EFFECTIVENESS OF THE AIRBAGS.

Start by slipping the seat cover over the back of your vehicle's seat and pulling it down all the way over seatback. Ensure that the holes for the headrest in the covers line up with the grommets in the seat.

Tuck the connecting flaps of the seat cover between the seat base and seat back. Folding the seat forward may make this process easier. Zip up all zippers on the seat cover (if applicable). Attach the connecting flaps with the hook and loop fasters on the back of the seat cover.

Install the seat bottom cover over the seat base and pass the connecting straps between the seat back and seat base. Make sure the buckles and straps are tucked all the way through the crevice between the seat back and base.

Seat Covers Installation: continued

Underneath the seat, connect and tighten the buckles and straps from the back of the seat cover with the buckles at the front of the seat cover.



USE THE STRAPS FOR THE FINAL ADJUSTMENT ONLY. DO NOT PULL TOO HARD OR OVER TIGHTEN THE STRAPS. THIS COULD CAUSE DAMAGE TO THE SEAT COVERS.

Pull the sides of the seat cover all the way down over the sides of the seat base. Attach the elastic straps with hooks to the buckled straps under the seats or to part of the underside of the seat base.

```
ACAUTION A
```

DO NOT ATTACH STRAPS OR HOOKS TO ANY PART OF THE SEAT THAT MIGHT IMPEDE OPERATION OF THE SEAT.

Finish installation by adjusting the seat covers around and behind all seat levers, adjusters, covers, and trim.



Seat covers can be carefully tucked under and around the headrest grommets. This will provide a more finished look and retain access to headrest release tabs.



Finally, Install headrest covers and reinstall headrests.

Product Care:

Periodic adjustments to the seat covers may be necessary as the covers break-in and conform to your vehicle's seat. Seat covers can be spot cleaned with mild soap and water and a soft bristle brush. Do not machine wash.

Sunlight will naturally fade neoprene over time.

Seat covers are warrantied against defects in workmanship and materials, but not for fading due to normal UV exposure. See next page for complete warranty information.



BEFORE DRIVING, TEST THE OPERATION OF THE SEATS. IF THE SEAT OPERATION IS IMPAIRED BY THE COVER, MAKE ADJUSTMENTS TO THE INSTALLATION OF THE SEAT COVER, AND TEST THE OPERATION OF THE SEAT AGAIN. DO NOT DRIVE THE VEHICLE UNLESS THE SEATS OPERATE PROPERLY.

Further Information:

A Quadratec seat cover installation video is available @ www.quadratec.com

Quadratec[®] Exclusive One Year Limited Warranty

Your Quadratec[®] Diver Down[®] branded accessories are covered by the following **Limited Warranty** provided exclusively by Quadratec, Inc., 1028 Saunders Lane, West Chester PA 19380.

This **Limited Warranty** is the only warranty made in connection with your purchase. Quadratec neither assumes nor authorizes any vendor, retailer or other person or entity to assume for it any other obligation or liability in connection with this product or **Limited Warranty**. This **Limited Warranty** does not apply and is not cumulative to any accessory or part distributed by Quadratec for which the Manufacturer provides a separate written warranty.

What is Covered: Subject to the terms, exclusions and limitations herein and with respect only to Quadratec branded accessories first sold in the United States, Quadratec warrants to the initial retail purchaser only that your Quadratec accessory shall be free of defects in material and workmanship: for a period of one (1) years from date of retail purchase.

This **Limited Warranty** is not assignable and shall terminate upon sale of the vehicle upon which the Quadratec accessory is installed or other transfer third persons.

All other warranties are hereby disclaimed, except to the extent prohibited by applicable law in which case any implied warranty of merchantability or fitness for a particular purpose on this product is limited to 1 year from date of initial retail sale. Quadratec reserves the rights to: (a.) require invoice or other proof your accessory is within the terms of this **Limited Warranty** as a condition of warranty service and, (b.) make future revisions to this product and **Limited Warranty** without prior notice or obligation to upgrade your product.

What is Not Covered:

Your Quadratec Limited Warranty does not cover products or parts Quadratec determines

to have been damaged by or subjected to: (a.) installation damage, alteration, modification, combination with other parts, failure to maintain or improper repair or service, (b.) normal wear & tear, UV fading, cosmetic damage or damage from moisture or water immersion, (c.) Acts of God, accidents, misuse, negligence, inadequate mounting or impact with vehicle(s), obstacles or other aspects of the environment, (d.) theft, vandalism or other intentional damage.

Remedy Limited to Repair/Replacement: The exclusive remedy provided hereunder shall, upon Quadratec inspection and at Quadratec's option, be either repair or replacement of product or parts (new or refurbished) covered under this Limited Warranty. Customers requesting warranty consideration should first contact Quadratec to obtain a RGA number (610-701-3336). All labor, removal, shipping and installation costs are customer's responsibility.

Other Limitations - Exclusion of Damages -Your Rights Under State Law:

In consideration of the purchase price paid, neither Quadratec nor any independent Quadratec distributor/licensee are responsible for any time loss, rental costs, or for any incidental, consequential, punitive or other damages you may have or incur in connection with any part or product purchased. Your exclusive remedy hereunder for covered parts is repair/replacement as described above.

This **Limited Warranty** gives you specific rights. You may also have other rights that vary from state to state. For example, some states do not allow limitations of how long an implied warranty lasts and /or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you.

©Quadratec, Inc. 2020. All Rights Reserved. Part [#]12999.3160 A4

